



# Installation Guide



**1**

We recommend the removal of all vegetation from the MSE wall joints prior to the installation of the FDS.



**2**

Evaluate the MSE wall panel joint widths and select the appropriate FDS product.

**3** The correct size FDS is selected and installed into the MSE wall joints using a narrow blunt tool.



	MSE JOINT SIZE
MODEL	COVERAGE
FDS058	< 3/8"
FDS100	≥ 3/8" to 3/4"
FDS138	≥ 3/4" to 1"
FDS158	> 1" to 1 3/8"

**4** Insert FDS 1" into joint. FDS should be installed into the joint with the FDS seam facing towards the wall.







**5** Make a 90° cut with sharp, industrial grade serrated scissors. *Do not use a utility knife.*



**6** The FDS size selected should compress to fit tightly into the joint (adhesive is not necessary).



**7** Where vertical and horizontal joints intersect, insure that FDS seals tightly and there are no gaps between material sections.



This is an example of a completed MSE wall correctly fitted with FDS.

